

Installation

Switching OFF



1. Press the power button on the left side of the battery for 6 seconds and then turn off the battery disconnect switch on the right side of the battery.
2. Turn off the battery disconnect switch located on the lower center inverter.
3. Switch off the PV switch at the bottom left of the inverter.
4. Switch off the PV switch between the PV string and the inverter if there is any.
5. Turn off the AC disconnect switch between the inverter and the load if there is any.
6. Turn off the AC disconnect switch between the inverter and the grid.

Installation

Switching ON



1. Briefly Press the Silver Power Button on the RH side of the Battery.
2. Then Turn on the Circuit Breaker on the side of the Battery.
3. Repeat this for all additional batteries ensuring they are turned on within 30 seconds of each other.
4. Then turn on the Circuit breaker on the inverter.
5. Then turn on the AC supply and any DC if there is any.
6. Wait for system to fully switch on (5-10 minutes)

