

Powering off the Smile-B3 System



1. If backup load is applied, turn off the external backup AC breaker;
2. Press the button on the battery until the battery LED off;
3. Turn off the main battery switch of B3 system;
4. Turn off the external grid AC breaker

Powering on the Smile-B3 System



System shall be turned on in the correct sequence to avoid any damage.

1. Turn on the 80A&63A battery switch of B3 system;
2. Press the button on the battery until the battery LED lights;
3. Turn on the external grid AC breaker;
4. If PV is applied, turn on the PV-INV switch;
5. If backup load is applied, turn on the external backup AC breaker; if not, keep it off.